

# NASA TECH BRIEF

## NASA Pasadena Office



NASA Tech Briefs announce new technology derived from the U.S. space program. They are issued to encourage commercial application. Tech Briefs are available on a subscription basis from the National Technical Information Service, Springfield, Virginia 22151. Requests for individual copies or questions relating to the Tech Brief program may be directed to the Technology Utilization Office, NASA, Code KT, Washington, D.C. 20546.

### Measurement of Trap Density in Dielectric Film

#### The problem:

Dielectric films such as  $\text{SiO}_2$  and  $\text{Si}_3\text{N}_4$  are commonly used in insulated-gate field-effect transistors (IGFET's). The quality of these films has an important bearing on the performance and life expectancy of the transistors. An important determinant of quality in these films is trap density. A trap is a localized imperfection in the film that can accept carriers (electrons and holes) and therefore effect the local charge. A method is needed to determine the trap density and hence to evaluate the film quality.


#### The solution:

A new method has been developed for measuring the trap density of dielectric film using a basic circuit as shown in the illustration.

#### How it's done:

The test device is connected into the circuit as shown. With a selected constant potential  $V_{g0}$  applied to the gate, a constant drain potential  $V_D$  drives a drain current  $I_D$  through the conducting channel between the source and the drain. A constant-current generator drives a selected reference current  $I_0$  into the junction at A so that the difference in current  $I_D - I_0$  passes through resistor  $R_0$ . The resulting voltage drop across  $R_0$  is applied to the input of the feedback amplifier.

When  $I_D$  equals  $I_0$ , the amplifier output is zero. When  $I_D$  differs from  $I_0$ , the amplifier output voltage  $V_{g1}$  is proportional to the change in  $I_D$  which corresponds to the change in channel conductance.



Circuit for Determining Trap Density

(continued overleaf)

When the switch is closed, a selected initial bias potential  $V_{g0}$  is applied to the gate. The  $V_{g0}$  is selected to give an approximately zero output from the amplifier immediately after closing the switch, i.e., a near-balance condition in which  $I_D$  is approximately  $I_0$ . This condition is reached by trial and error by repeatedly observing the initial response and adjusting the  $V_{g0}$ . The balancing step is necessary to minimize the required amplifier output and thus to reduce feedback error. The algebraic sum of the observed output voltage  $V_{g1}$  and the bias  $V_{g0}$  at the instant the switch is closed is the unperturbed gate voltage (before space-charge injection). The sum thus determines the field at the interface which is maintained constant during the measurement.

With the switch closed, the output voltage  $V_{g1}$  increases, compensating for the injected space charge so that the channel conductance, and thus the interface field, is maintained nearly constant (i.e.,  $I_D = I_0$ ). This change in  $V_{g1}$  is displayed as a function of time or log time on an oscilloscope or a chart recorder and is used to calculate the trap density.

**Note:**

Requests for further information may be directed to:

Technology Utilization Officer  
NASA Pasadena Office  
4800 Oak Grove Drive  
Pasadena, California 91103  
Reference: TSP75-10204

**Patent status:**

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning non-exclusive or exclusive license for its commercial development should be addressed to:

Patent Counsel  
NASA Pasadena Office  
4800 Oak Grove Drive  
Pasadena, California 91103

Source: John E. Guisinger and Joseph Maserjian of  
Caltech/JPL  
(NPO-13443)